HPE0-S50^{Q&As}

Integrating HPE Synergy Solutions

Pass HP HPE0-S50 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

https://www.pass2lead.com/hpe0-s50.html

100% Passing Guarantee
## 100% Money Back Assurance

Following Questions and Answers are all new published by HP Official
Exam Center

⚙ **Instant Download** After Purchase

⚙ **100% Money Back** Guarantee

⚙ **365 Days** Free Update

⚙ **800,000+** Satisfied Customers

![Pass2Lead logo](https://Pass2Lead.com)
QUESTION 1

Refer to the exhibit.

Based on the Synergy configuration shown, what will be the outcome in the event of an end-of-row (EoR) switch failure?

A. Smartlink will be triggered

B. There will be no NIC failover.

C. Uplink bandwidth will decrease.

D. Server and downlinks will fail.

Correct Answer: B

QUESTION 2

A customer is using HPE Synergy Composer to manage the compute module and 3PAR volume attachments. The datastore attached to VMware servers has run out of space. What is the most efficient procedure the Synergy integrator should follow to extend the volume with minimum effect on the compute modules?

A. Set the volume to maintenance mode and increase the volume in 3PAR SSMC.

B. Create a snapshot and increase the capacity of the snapshot directly in the Synergy Composer.

C. Increase the capacity of the volume in the combined profile form.

D. Increase the capacity of the volume directly in the Synergy Composer.

Correct Answer: D

QUESTION 3

![Pass2Lead](https://Pass2Lead.com)
Which component of the HPE Synergy solution provides a customer with the ability to rapidly provision a consistent operating environment?

A. OpenView

B. Reference Architecture

C. Composer

D. Image Streamer

Correct Answer: C

QUESTION 4

A customer has moved a USB bootable drive to another compute module but the compute module fails to boot from the USB device.

What should the Synergy integrator do to resolve this issue?

A. In the server Profile, make sure OS Deployment is set to Deployment Plan.

B. Use UEFI System Utilities to disable the B140i RAID controller.

C. Verify that the USB drive key is enabled in UEFI System Utilities.

D. Make sure PXE boot is disabled.

Correct Answer: B

QUESTION 5

Refer to the exhibit.

A customer has an HPE Synergy 2-frame configuration, as shown. The customer has a new project and needs to increase the number of compute modules. What is the maximum number of compute nodes that the customer\\'s fabric could support?

A. 24

B. 36

C. 48

D. 60

Correct Answer: B